



NOTE: Paraseal products require a min of 24 PSF of compaction/confinement in order to function as designed.

NOTE: Use washer headed nails in the seam areas only as needed. All nails to be located at the seam lap and covered by or driven through a piece of Parastick N Dry.

TREMCO <small>www.tremcosealants.com</small> 3735 Green Road * Beachwood, OH 44122 Phone : 866-209-2404 * Fax: 216-766-5535	Detail: CAST IN PLACE THROUGH FLOOR PENETRATION (BENTONITE SIDE UP)(NON-SUBMERGED)			Sheet Number:	File Name:	Rev #
	This detail is intended for conceptual purposes only.	Drawn by: MI	Checked by: JM	Scale: None	Date: 5/24/2016	B-BSOG-07-LG20