



NOTE: Use washer headed nails in the seam areas only as needed. All nails to be located in the seams and covered with Para JT Tape.

NOTE: Paraseal products require a min of 24 PSF of compaction/confinement in order to function as designed.

TREMCO

www.tremcosealants.com

3735 Green Road * Beachwood, OH 44122
Phone : 866-209-2404 * Fax: 216-766-5535

Detail: CAST IN PLACE THROUGH FLOOR PENETRATION (BENTONITE SIDE UP)

This detail is intended for conceptual purposes only.

Drawn by: MI

Checked by: JM

Scale: None

Sheet Number:

Date: 8/17/2015

File Name:

BSOG-03-GM20

Rev #

00