



NOTE: When pouring concrete over the Paraseal GM/LG pour either directly on top of the seam or towards the closed edge of the seam so as not to lodge concrete between the lapped seam.

Use washer headed nails in the seam areas only as needed. All nails to be located in the seams and covered with Para JT Tape.

NOTE: Paraseal products require a min of 24 PSF of compaction/confinement in order to function as designed.

<b>TREMCO</b> www.tremcosealants.com 3735 Green Road * Beachwood, OH 44122 Phone : 866-209-2404 * Fax: 216-766-5535	Detail: BSOG TYPICAL SEAM DETAIL (BENTONITE SIDE UP)			Sheet Number:	File Name:	Rev # 00
	This detail is intended for conceptual purposes only.	Drawn by: MI	Checked by: JM	Scale: None	Date: 8/17/2015	