



NOTE: Paraseal products require a min of 24 PSF of compaction/confinement in order to function as designed.

NOTE: Not recommended for use in submerged conditions.

NOTE: All fasteners shall be located in the seam area. Fasteners not located in the seam areas shall be driven through or covered by Parastick N Dry that is adhered with Paraprimer.

TREMCO

www.tremcosealants.com

3735 Green Road * Beachwood, OH 44122
Phone : 866-209-2404 * Fax: 216-766-5535

Detail: BLINDSIDE LAGGING WALL - BACKLAGGED

This detail is intended for conceptual purposes only.

Drawn by: MI

Checked by: JM

Scale: None

Sheet Number:

Date: 5/27/2016

File Name:

BSW-07-LG20

Rev #

00