



NOTE: Fasteners not located in the seam area shall be driven through a piece of Superstop Waterstop or Parastick N Dry; otherwise, fastener heads are to be covered with Parastick N Dry that is adhered with Paraprimer.  
 NOTE: Paraseal products require a min of 24 PSF of compaction/confinement in order to function as designed.

**TREMCO**

www.tremcosealants.com

3735 Green Road \* Beachwood, OH 44122  
 Phone : 866-209-2404 \* Fax: 216-766-5535

Detail: PARASEAL LG - TYPICAL SEAM AT BLINDSIDE LAGGING WALL

This detail is intended for conceptual purposes only.

Drawn by: MI

Checked by: JM

Scale: None

Sheet Number:

Date: 5/24/2016

File Name:

BSW-08-LG20

Rev #

00