



- Lagging
- TREMDrain 1000 only to be applied above the water table
- TREMDrain drain core to be sealed with a cant bead of Dymonic 100, Vulkem 116 sealant or TREMPROOF 250 GC - T full perimeter of the tie-back.
- Fill any void solid with grout
- PVC cap or Pre-fabricated boot with Paramastic fill
- 3" Parastick N Dry adhered to the Paraseal GM/LG and the PVC cap with ParaPrimer and tied with wire.
- Shotcrete or poured in place wall
- Paraseal GM/LG target sheet
- Para JT Tape
- 3" Parastick N Dry
- Soil
- Paraseal GM/LG



NOTE: Paraseal products require a min of 24 PSF of compaction/confinement in order to function as designed.

TREMCO
 www.tremcosealants.com
 3735 Green Road * Beachwood, OH 44122
 Phone : 866-209-2404 * Fax: 216-766-5535

Detail: NON-DETENTIONED TIE-BACK
 This detail is intended for conceptual purposes only.

Drawn by: MI
 Checked by: JM
 Scale: None

Sheet Number:
 Date: 8/19/2015

File Name:
 BSW-09-GM20

Rev #
 00