



When spraying shotcrete or other materials against Paraseal LG, spray either directly at the seam or at the closed edge of the seam so as not to lodge sprayed materials between the lapped sheets. Never spray into open edge of seam.

Seams may run either horizontal or vertical. When running horizontal, the open edge of the 4" seams shall be aiming up or shingled as shown.

Lap seams minimum 4" and secure with wide crown box staples located at 3" O.C. In order to prevent penetrations and damage to the membrane use concrete dobies or plastic sand chairs between the rebar and the Paraseal LG to hold the Paraseal LG tight against the lagging.

NOTE: Paraseal products require a min of 24 PSF of compaction/confinement in order to function as designed.

NOTE: Not recommended for use in submerged conditions.

NOTE: Fasteners only to be located at the seams; all fasteners located outside of the seam area shall be driven through a piece of Superstop Waterstop or covered with Parastick N Dry that is adhered with Paraprimer.

**TREMCO**

www.tremcosealants.com

3735 Green Road \* Beachwood, OH 44122  
Phone : 866-209-2404 \* Fax: 216-766-5535

Detail: BLINDSIDE WALL TYPICAL SEAM DETAIL

This detail is intended for conceptual purposes only.

Drawn by: MI

Checked by: JM

Scale: None

Sheet Number:

Date: 5/24/2016

File Name:

BSW-09-LG20

Rev #

00