



When spraying shotcrete or other materials against Paraseal GM/LG, spray either directly at the seam or at the closed edge of the seam so as not to lodge sprayed materials between the lapped sheets. Never spray into open edge of seam.

Seams may run either horizontal or vertical. When running horizontal, the open edge of the 4" seams shall be aiming up or shingled as shown.

Staple seams only through the HDPE area as shown and overlap all seams 4" and JT Tape all seams. Install Parastick N Dry Tape over seam edge with Paraprimer.

In order to prevent penetrations and damage to the membrane use concrete dobies or plastic sand chairs between the rebar and the Paraseal GM/LG to hold the Paraseal GM/LG tight against the lagging.

NOTE: Paraseal products require a min of 24 PSF of compaction/confinement in order to function as designed.

<b>TREMCO</b> www.tremcosealants.com 3735 Green Road * Beachwood, OH 44122 Phone : 866-209-2404 * Fax: 216-766-5535	Detail: BLINDSIDE WALL TYPICAL SEAM DETAIL			Sheet Number:	File Name:	Rev # 00
	This detail is intended for conceptual purposes only.	Drawn by: MI	Checked by: JM	Scale: None	Date: 8/19/2015	