



Install primary Paraseal LG sheet by cutting small holes into sheet which correspond to stud locations and slip sheet over stud. Nail at 12" O.C. down both sides.

12" Wide strip of Paraseal LG target sheet. Cut small holes in Paraseal LG and slip over studs.

Wrap stud with Superstop Waterstop and secure in place using a tie-wire.

NOTE: Paraseal products require a min of 24 PSF of compaction/confinement in order to function as designed.

TREMCO

www.tremcosealants.com

3735 Green Road * Beachwood, OH 44122
Phone : 866-209-2404 * Fax: 216-766-5535

Detail: PARASEAL LG INSTALLATION AT STUDS OR FROM TIES

This detail is intended for conceptual purposes only.

Drawn by: MI

Checked by: JM

Scale: None

Sheet Number:

Date: 5/24/2016

File Name:

BSW-18-LG20

Rev #

00