



NOTE: After all detailing is completed, center of the Mike Bracket shall be filled full with a paste. The paste shall be made by adding 1 gallon of Bentonite granules to 2 gallons of Paramastic.

NOTE: Upon placement of concrete wall and the removal of the one sided forms, remove the taper tie rods and fill the rod holes with an injection non-shrink epoxy grout.



www.tremcosealants.com
 3735 Green Road * Beachwood, OH 44122
 Phone : 866-209-2404 * Fax: 216-766-5535

Detail: MIKE BRACKET FOR PARASEAL LG 20 MIL

This detail is intended for conceptual purposes only. Drawn by: MI Checked by: JM Scale: None

Sheet Number:
 Date: 5/24/2016

File Name:
 BSW-19-LG20

Rev #
 00