



Fold Paraseal LG over as shown so HDPE side protects bentonite component and temporarily nail in place every 24" O.C. using washers in order to enable easy removal later.

It is also acceptable to place a temporary form above lagging to temporarily tack the membrane in place in order to protect it from damage.

Paraseal LG with HDPE side against lagging, or other approved retention system.

Wood lagging

NOTE: Paraseal products require a min of 24 PSF of compaction/confinement in order to function as designed.

TREMCO
 www.tremcosealants.com
 3735 Green Road * Beachwood, OH 44122
 Phone : 866-209-2404 * Fax: 216-766-5535

Detail: TYPICAL TEMPORARY TERMINATION AT TOP OF EARTH RETAINING SYSTEM

This detail is intended for conceptual purposes only.

Drawn by: MI

Checked by: JM

Scale: None

Sheet Number:

Date: 5/24/2016

File Name:

BSW-25-LG20

Rev #

00