

Temporary termination

Reference seam detail

TREMDrain 1000 to be applied above watertable only.

Seams overlapped 4" min and secured with wide crown box staples at 3" O.C.

Paraseal LG

TREMproof 260 at 100 wet mils

Superstop Waterstop at all cold joints

Tie-back

Reference penetration detail

Steel pile (I-Beam)

Place cement board over the soldier piles at the area to be cut.

Reference Mike Bracket Detail

Lagging. Slurry fill lagging in place; as to prevent movement. Do not use nails to secure lagging at I-Beam.

All voids greater than 1" in width, and/or 1/2" in height or depth shall be repaired with non-shrink grout, minimum 24 gauge sheet metal or treated plywood

Paraseal LG starter strip to extend 6" min. below top of footing/mat slab

NOTE: Paraseal products require a min of 24 PSF of compaction/confinement in order to function as designed.

NOTE: Not recommended for use in submerged conditions.

NOTE: All fasteners shall be located in the seam area. Fasteners not located in the seam areas shall be driven through or covered by Parastick N Dry that is adhered with Paraprimer.

**TREMCO**

www.tremcosealants.com

3735 Green Road \* Beachwood, OH 44122  
Phone : 866-209-2404 \* Fax: 216-766-5535

Detail: TREMproof TWS - BLINDSIDE LAGGING WALL

This detail is intended for conceptual purposes only.

Drawn by: MI

Checked by: AC

Scale: None

Sheet Number:

Date: 5/27/2016

File Name:

TWS-BSW-01

Rev #

00