



NOTE: After all detailing is completed, center of the Mike Bracket shall be filled full with a paste. The paste shall be made by adding 1 gallon of Bentonite granules to 2 gallons of Paramastic.

NOTE: Upon placement of concrete wall and the removal of the one sided forms, remove the taper tie rods and fill the rod holes with an injection non-shrink epoxy grout.

TREMCO

www.tremcosealants.com

3735 Green Road * Beachwood, OH 44122
Phone : 866-209-2404 * Fax: 216-766-5535

Detail: TREMproof TWS - MIKE BRACKET

This detail is intended for conceptual purposes only.

Drawn by: MI

Checked by: AC

Scale: None

Sheet Number:

Date: 5/27/2016

File Name:

TWS-BSW-13

Rev #

00