



- Lagging
- TREMDrain 1000 as specified (only to be applied above the water table)
- TREMDrain 1000 drain core to be sealed with a cant bead of Dymonic 100 sealant around the full perimeter of the tie-back.
- Fill any void solid with grout
- PVC cap or Pre-fabricated boot with Paramastic fill
- 3" Parastick N Dry adhered to the Paraseal LG and the PVC cap with ParaPrimer and tied with wire.
- Shotcrete or poured in place wall
- Paraseal LG target sheet to be secured with nails with washers at each corner and with wide crown box staples located at 3" O.C. thereafter.
- TREMproof 260 at 100 wet mils
- Paraseal LG

Staple

Soil

NOTE: Paraseal products require a min of 24 PSF of compaction/confinement in order to function as designed.

TREMCO www.tremcosealants.com 3735 Green Road * Beachwood, OH 44122 Phone : 866-209-2404 * Fax: 216-766-5535	Detail: TREMproof TWS - NON-DETENTIONED TIE-BACK			Sheet Number:	File Name:	Rev # 00
	This detail is intended for conceptual purposes only.	Drawn by: MI	Checked by: AC	Scale: None	Date: 5/27/2016	