



Tremdrain Drainage Mat. (Filter Fabric Facing Installer)

Separate Piece of Filter Fabric Wired Around Pipe and Nailed in Place.

Pipe.

Paraseal, Paraseal "Washer" and Paramastic Installed Around Pipe. Tape "Washer" to Pipe and Paraseal Using Para JT Tape.

NOTE:
 Consult Tremco Technical Services Or Your Local Tremco Representative For Appropriate Paraseal and Tremdrain Products.

Pipe Penetration thru Backfilled Wall.

No.	Date	Description	By
<p>TREMCO. 3735 Green Road Beachwood, Ohio 44122 216-292-5000</p>			
<p>Project: Drainage Systems</p>			
Drawn by:	J. Davis	Scale:	Not To Scale
Date:	08/01/01	Drawing/Index No.:	DS-11